

Ripmax
wots·wot
FOAM-E BY **CHRIS FOSS**

Top Wing Clamp Notice

Variations in production mean it may be necessary make a minor change to the top wing clamp so that the wing sits properly on the centre struts. Using a knife carefully trim 1mm off the top of the seat clamp as indicated by the dotted lines. Test fit the wing, if it rocks remove and trim a small amount more until the wing sits flush.

